


Electrical Distribution

The electrical distribution within the apartment is provided via a consumer unit located within the services cupboard.



NOTE:

The consumer unit is LIVE and maintenance must only be carried out by a qualified electrician.

If for any reason the unit requires isolating, this is achieved by carefully lifting up the front cover and switching the main switch to the off position. For your convenience the miniature circuit breakers (m.c.b.'s) within the consumer unit are labelled giving details of the equipment served by each m.c.b.

NOTE:

If you are unsure, do not attempt this procedure.